Quick start guide

Milling Machine

Proxxon Milling Machine











Machine Appearance & Accessories




echnoventor


Machine Startup & Testing








Press the ON switch(green) at the top of machine.




Move X,Y,Z axis using handwheel as per requirement.

6




Select High/Low speed using switch provided.


3




height by handwheel.



Pull lever provided next to spindle for drilling operation.





After cutting operations switch OFF the machine and remove workpiece safely.

DO's

- Only work with safety glasses!
- Disconnect the mains plug before you do any adjustments or when exchanging tool.
- Place sufficient distance from machine during operation.
- Always engage the collet chuck in the swivel nut first.
- Always make sure that the collet chuck and the milling shaft have the matching diameter.
- Clean the device after every use with a soft cloth, hand brush or brush. A vacuum cleaner can also be used.

DONT's

- Do not dispose of with household rubbish.
- Do not insert the mains plug before completing the assembly work as the machine could be switched on unintentionally.
- Never insert the collet chuck singly into the spindle receiver.
- Do not dispose of the device in the household waste. The device contains valuable substances which could be recycled.
- X Never hold the tools with bare hands.

Machine Specifications

Power Supply	230V. 400W. 50/60Hz.
Sleeve stroke	30mm.
Spindle speeds	200 - 4,000rpm.
Throat	125mm.
Column	120 x 100 x 430mm.
Table	T slotted 400 x 125mm.
Transverse range	vertical (Z-axis) 220mm, transverse (X-axis) 310mm, depth (Y-axis) 100mm.
Dimensions:	H = 750mm, W = 550mm, D = 550mm.
Weight approx.	47kg.
Collet type	ER 20 (6-8-10-12MM)

For any queries contact:

8828294964 / 7304419928